


Hi-Sight: Operation


Hi-Sight Poster Frames incorporate a magnetic poster cover & a poster carrier.
No step ladders or tools are needed when changing posters.

1. Open the cover.




a

Press inside the border to release the magnetic seal.




b

Open the cover sheet.




2. Lower the poster carrier.



Locators

a Lift the poster carrier to release the locators from the frame.



b

pull

c lower


Pull the poster carrier towards you & then lower.




d

Guide the poster carrier gently downwards.


3. Fit the poster.




a Open the clips located at the top of the poster carrier.



Tip. Roll the poster up before fitting it.



b Close the clips to pierce the poster.



c Gently allow the poster to unroll.

4. Completion.


a

Raise the loaded poster carrier.



b

Engage the locators back into the frame & check that the poster is squarely fitted.



c

IMPORTANT
Smooth down the perimeter of the poster cover.

